



NOTES:

1. REMOVE EXISTING PCC AND/OR HMA TO SOUND CONCRETE. IF PCC REMOVAL DEPTH EXCEEDS $T_e/2$, PERFORM FULL DEPTH REPAIR.
2. AFTER SAWING, REMOVE EXISTING HMA AND PCC BY JACKHAMMERING AND/OR AIR BLASTING.

FILE NO.: 2750-050
APPROVAL DATE: APRIL 2003
REVISION NO.: 1
REVISION DATE: MAY 2014

CEDAR RAPIDS METROPOLITAN AREA
STANDARD DETAILS FOR PUBLIC IMPROVEMENTS

PARTIAL DEPTH JOINT
REPAIR WITH HMA

NO.
2750-050